

## Nyon at a glance



- A Motor performance
- **B** Performance indicator
- Current speed
- D Time
- E Current riding mode

- F Connected heart rate sensor
- G Bicycle light switched on
- H Battery charge level
- Remaining range
- J Micro-AB-USB port

## Use the + and - buttons to select one of 4 assisted riding modes

Eco Effective support for the greatest range
Tour Consistently reliable support for long rides

**Sport** Powerful support for universal uses

eMTB\* Progressive, dynamic support for a natural riding sensation

Turbo Maximum support for a sporty ride

#### **Functions**







# **Kiox** – sporty connectivity



## Kiox at a glance



Switching on/off

- A Walk assistance
- Cursor buttons: toggle between screens & settings
- Select button
- Performance indicator
- E Current speed compared to average speed
- F Time or speed

- G Current riding mode
- H Bicycle light switched on
- Battery charge level
- J eShift (optional)
- K Current speed
- Motor performance
- M Bicycle light on/off

#### Use the + and - buttons to select one of 4 assisted riding modes

Eco Effective support for the greatest range Consistently reliable support for long rides

**Sport** Powerful support for universal uses

eMTB\* Progressive, dynamic support for a natural riding sensation


Turbo Maximum support for a sporty ride

## **Functions**











## Intuvia at a glance



- A Walk assistance
- **B** Reset counters
- C Shift recommendation
- Current speed
- E Battery charge level
- F Current riding mode
- G Information button: toggle between the various display options (trip distance, trip time, average, range)
- H Bicycle light on/off

## Use the + and - buttons to select one of 4 assisted riding modes

Eco Effective support for the greatest range
Tour Consistently reliable support for long rides

**Sport** Powerful support for universal uses

eMTB\* Progressive, dynamic support for a natural riding sensation

Turbo Maximum support for a sporty ride



## **Purion** – the compact purist





## **Purion** at a glance



#### **Functions**

- ① Long press: Light on/off
- Long press: Display trip distance, total distance and range
- (2) Short press: Switch ride modes
- → + Long press: Reset the trip distance or range display
- A Current speed
- B Range
- C Battery charge level
- Activate walk assist, keep pressed for support

Click	Short	Medium	Long	
	up to 1 sec	up to 2.5 sec	more than 2.5 sec	

#### Use the + and - buttons to select one of 4 assisted riding modes

Eco Effective support for the greatest range
Tour Consistently reliable support for long rides

**Sport** Powerful support for universal uses

eMTB\* Progressive, dynamic support for a natural riding sensation

Turbo Maximum support for a sporty ride

